



AIR FILE: FRV-60N

1 File lock screw	F-60-01	14 Rear	F-60N-14
4 Piston extension	F-60-04	15 O-ring(3)	F-60-15
5 Support	F-60-05	16 Endcap(2)	F-60-16
6 Spring	F-60-06	17 Valve stem	F-60N-17
7 Spring	F-60-07	18 O-ring	F-60-18
8 Cylinder	F-60-08A	19 Ring	F-60-19
	or F-60-08B	20 Seal ring	F-60-20
9 Piston	F-60-09A	21 Spring support	F-60-21
	or F-60-09B	22 Stop ring	F-60-22
10 Piston ring	F-60-10	23 Hex key	F-60-23
11 Limit ring	F-60-11	24 Inlet fitting	F-60-24
12 Ball	F-60-12	25 Tubing w fitting	F-60-25
13 Housing	F-60-13A		
	or F-60-13B		

Note: It is important to use the complete part number when ordering spare parts or the part you receive may be for an older model!